

Instructions Coffee Maker

COFFEE MAKER INSTRUCTIONS

- 1. Fill the coffee maker with cold water to the desired level before plugging in the maker.
- 2. Wet the basket and pour in the coffee (for a 55 cup maker 1 pound of coffee is required)
- 3. Plug into an outlet (1 maker per circuit) allow 1 minute per cup to brew.